



## Arresta™ Device Selection and Dispersion Settings Chart

1. Estimate the size of the indoor space to be treated
2. Select the appropriate EPA-registered device
3. Make sure to use the correct settings
4. Follow all directions on the label

DEVICE	SQ FT	ROOM DIMENSIONS	CEILING HEIGHT	CU FT	DURATION	DEVICE SETTINGS (In seconds)
Aura	100	10'x10'	8	800	2hr	50 on - 220 off
	200	20'x10'	8	1,600	2hr	300 on - 160 off
	400	20'x20'	8	3,200	2hr	900 on - 100 off
	800	20'x40'	8	6,400	2hr	900 on - 100 off
Clarify	800	20'x40'	10	8,000	2hr	10 on - 60 off at 3% volume
	2,500	50'x50'	10	25,000	2hr	10 on - 30 off at 3% volume
	5,000	71'x70'	10	50,000	2hr	20 on - 30 off at 5% volume
	10,000	100'x100'	10	100,000	2hr	40 on - 30 off at 5% volume
MPU	5,000	71'x70'	20	100,000	2hr	60 on - 30 off at 7% volume
	10,000	100'x100'	20	200,000	2hr	120 on - 10 off at 10% volume
	20,000	100'x200'	20	400,000	2hr	210 on - 10 off at 10% volume